

## 2in x 3in Upright Pulley Bracket Assembly

When using the TUT Pulley Brackets on a 2in x 3in upright there are two options for mounting. Please see images below to create the set up that works best for you. (Attach spacers to pulley brackets using preferred super glue)



